

REV: 09
August 9th 2024

Avid Controls Inc.
41261 Park 290 Drive, Waller, TX 77484, USA
info@avidcontrolsinc.com
(+1) (281) 640-8600


**THIS DATA SHEET CONTAINS AN INSTALLATION CHECKLIST THAT MUST BE
COMPLETED AND RETURNED TO INFO@AVIDCONTROLSINC.COM
SEE APPENDIX A**

AVID Controls Inc. pursues a policy of continuous product improvement and innovation. This may not be the latest revision of this publication and may not reflect all current product changes. Contact AVID Controls Inc. for the latest revision of this data sheet and information on other product enhancements.

INTENTIONALLY BLANK

Contents

1. Introduction	4
2. WARNINGS	4
3. Tools and Equipment Required.....	5
4. Necessary Avid Supplied Bill of Materials.....	5
5. Upgrade Kit Parts List.....	6
6. DC Fuses for Inter-Module Connection.....	6
7. Overview of SWP Type 27 Cabinet Layout.....	7
8. Prior to Removal of MVDL800 Delta Modules.....	8
9. Remove, Clean and Retain Cabinet Shrouds.....	10
10. Disconnect MVDL800 DELTA Modules	11
11. Remove MVDL800 DELTA Modules, Replace Hoses	12
12. Modify Side Panel of Grid Cabinet (Cubicle 1 A12-1) & Replace Inner Cubicle Bonding Bracket ..	13
13. Install the AEI900L/AEI1000L Modules.....	14
14. Connect Coolant Hoses, Front and Back.....	16
15. Reinstall DC Cables, Busbars and Fuse Links	17
16. Reinstall A12-1 Side Phase Cables	18
17. Reinstall A12-2 AC Cables	19
18. Reinstall AEI Cover Plates.....	20
19. Install Auxiliary Power Units.....	21
20. Optional Connection of Auxiliary 24VDC Supply to APUs	22
21. Install Ground Brackets and Ribbon Cables	23
22. Reinstall Lower Cubicle Shrouds.....	25
23. Reinstall Upper Cubicle Shrouds	26
24. Turbine Restart.....	27
25. Label CDCs	29
26. Attach Documents for Reference	30
27. Fit the Upgrade Identification Label	31
28. Document Revision History	32
29. Appendix A – Installation Checklist	33

AVID CONTROLS and the  logo are registered trademarks of Avid Controls Inc.

1. Introduction

- The following procedures are specific to the installation of the AVID AEI900L or AEI1000L liquid-cooled inverter module.
- These procedures detail how to upgrade a Siemens Wind Power 2.3MW Type 27 turbine from GE Power Conversion Delta modules to AEI (Avid Extreme Inverter) modules and associated installation kit.
- For reference, see the following AVID documents, which are supplied alongside this Installation Instruction:
 - DTS-MID0012 for additional specifications explicitly related to the AEI900L and AEI1000L
 - DTS-02175-ASY-A for additional specifications related to the Auxiliary Power Units (Type G)

2. WARNINGS

- Always refer to the Cautions and Warnings in the associated MV DELTA and MV3000 manuals when installing / commissioning / fault-finding any system containing an AEI900L or AEI1000L module.
- This equipment may be connected to more than one live circuit.
- **Disconnect all power sources before working on the equipment.**
- **Wait at least 8 minutes after isolating all power sources and check that the voltage between DC+ and DC- has reduced to a safe level before working on the equipment.**
- Surfaces on the coolant pipes can reach high temperatures and remain hot for some time after power is switched off.
- Ensure that all coolant has cooled to a safe temperature and the equipment is suitably drained and isolated before disconnecting the external pipework from the equipment.
- Figures are for reference only.
- It is recommended that all DC fuses are replaced during this upgrade – see section 6 for further details.
- Appendix A contains an installation checklist for the turbine upgrade. This must be completed and returned to info@avidcontrolsinc.com to activate the individual product warranties for the Avid equipment. Each field in the checklist requires either initials, the recording of specific information (such as parameter values) or “N/A” if not applicable.

3. Tools and Equipment Required

MV3000 Keypad with Cable	Diagonal wire cutters	8mm crescent wrench
Torx T25 Driver	Phillips #2 x 4" Screwdriver	3/16" x 4" Slotted Screwdriver
#3 Pozi-drive Screwdriver	Socket Wrench, 3/8" Drive	Torque Wrench, 3/8" Drive
5mm Socket, 3/8" Drive	8mm Socket, 3/8" Drive	10mm Socket, 3/8" Drive
17mm Socket, 3/8" Drive	Socket Extension 10" Long, 3/8" Drive	Adjustable Crescent Wrench, 1" Jaw Capacity
Laptop with Drive Coach and RS232	10" 1/4" Drive Extension [*1]	1/4" Hex to 1/4" Drive Socket Adapter [*1]
8mm 1/4" Drive Socket [*1]	Digital Voltmeter (DVM)	4 NM Torque Key [*1]
Hydrometer Kit	AEI/Delta Installation Dolly (if available)	Torque Seal [*1]
AEI/Delta Lift Hoist (if available)	Sheet metal / Lexan cutting tool (Dicfeos REX003 Double Head Sheet Nibbler or similar)	

**1: Provided as part of the upgrade kit. Used to secure and torque coolant hose clamps.*

4. Necessary Avid Supplied Bill of Materials

AVID Model Number	Qty.	Description
AEI900L-412100-00-[N]/[S]/[R]*2	6	Avid Extreme Inverter, 900A 690V, Plumbing Option A, without capacitor fans, [N]=New, [S]=Enhanced Reman., [R]=Reman.
OR		
AEI1000L-412100-00-[N]/[S]/[R]*2	6	Avid Extreme Inverter, 1000A 690V, Plumbing Option A, without capacitor fans, [N]=New, [S]=Enhanced Reman., [R]=Reman.
AEI-UPGR-KIT-04	1	AEI Upgrade Kit, APU-G, for SWP 2.3MW Type 27 Class Turbines

**2: Depending on the rating of the upgraded turbine, AEI900L or AEI1000L modules may be used*

5. Upgrade Kit Parts List


Item Reference	Qty.	Description
1	6	DC/DC Auxiliary Power Unit, Avid Model Number AEI-APU-G-00
2	1	Magnetically Attached Document Envelope
3	2	Identification Label for Upgraded Turbine
4	1	Pack of surface-prep wipes for labels & shrouds
5	8	Warning Label for CDC
6	2	Ribbon cable ground bracket
7	6	Hose for front manifold, straight 183mm long, 20mm ID
8	6	Hose for rear manifold, straight 275mm long, 20mm ID
9	24	Hose clamps
10	20 ft	PVC braided tubing, 0.25in ID
11	5	Tee connector for 0.25in ID tube, white nylon
12	1	Elbow connector for 0.25in ID tube, white nylon
13	1	Grounding bracket for inner cubicles
25	1	Torque marker – orange, 1oz tube
31	100	11-in black cable ties, 50lb
32	100	5-in black cable ties, 30lb

6. DC Fuses for Inter-Module Connection

- All Siemens Wind Power (and Siemens Gamesa Renewable Energy) 2.3MW and 3.6MW turbines configure the Delta/AEI modules in hard-paralleled “sister” units, with relatively small rating DC fuses to interconnect the “sisters”.
- Experience has shown that these fuses age with time, and that faults in the Delta modules can accelerate this aging – often leading to premature failure.
- It is therefore strongly recommended that these fuses always be replaced when this upgrade is performed.
- Failure to do so may result in failure of the fuses shortly after re-starting the turbine.
- These fuses are standard spares for all wind sites, so are not provided as part of the upgrade kit.

7. Overview of SWP Type 27 Cabinet Layout

Cabinet Section (See Plan View)	Contains
REACTOR	Main Grid Reactor
A12 GRID & GEN CONVERTER	Grid Generator Deltas, CDCs, and SMPS's
A1	Incoming Power F/ Low Voltage, Large Circuit Breakers & Transformers
MAIN BREAKER	Siemens Control
Control	Fuses, Circuit Breakers, Ethernet & Fiber Optic




Plan View

8. Prior to Removal of MVDL800 Delta Modules



- The removal process of the GE Power Conversion MVDL800 Delta modules should follow standard on-site procedures, including:
 - Power shutdown
 - Draining of liquid coolant
 - Disconnecting of all electrical power sources
 - Removal of SMPS
 - Removal of the MVDL800 Deltas

- Before removal of any connections or components, record the positions of the following.
 - All existing cables
 - Note the position of any relevant tie wraps
 - Identify the master SMPS for the grid and generator system. The master SMPS is mounted on the Delta module connected to PL2 of the associated CDC.
 - Keep all hardware, nuts, bolts, washers, thread protectors, etc.




Avid Extreme Inverter – Turbine Upgrade Installation Instructions, APU-G, SWP Type 27

- When removing the Master SMPS(s), record the positions of jumpers TP10 to TP13. These jumpers configure the over-voltage trip behavior. The AEI900L modules use this information for proper setup.





9. Remove, Clean and Retain Cabinet Shrouds

- Remove the upper and lower polycarbonate shrouds from the front of the GEN and GRID cabinets.
- Retain the shrouds for re-fitting after AEI installation.
- Retain the fixing screws.
- **It is highly recommended to clean these shrouds thoroughly before re-installation. A pack of cleaning wipes is included in the upgrade kit.**




10. Disconnect MVDL800 DELTA Modules

- Disconnect and remove all ribbon cables; carefully retain these for installation of AEI units.
- Remove all SMPS Modules and SMPS mounting plates.
- Carefully note all power cable positions, then remove them:



11. Remove MVDL800 DELTA Modules, Replace Hoses


- Remove all DELTA modules as shown; this will allow access to the rear and front hoses, as shown below.
- Replace all 12 hoses using hoses and clamps provided in the AEI upgrade kit, taking care to ensure their orientation matches that of the removed hoses.



- Tighten all hose clamps to 4Nm torque. A pre-set torque handle is provided in the upgrade kit for this purpose.
- **IT IS CRITICAL THAT THE HOSES ARE SECURELY INSTALLED AND THE CLAMPS TIGHTENED CORRECTLY. COOLANT LEAKAGE WILL IRREPARABLY DAMAGE THE INVERTER UNITS.**

12. Modify Side Panel of Grid Cabinet (Cubicle 1 A12-1) & Replace Inner Cubicle Bonding Bracket


- To allow new the grounding bracket and ribbons to fit correctly, cut metal section from left-hand shielding panel as shown below.
- DO NOT remove panel from cabinet, implement modification with panel in-situ.
- Ensure suitable precautions are taken to prevent metal particles (swarf) from contaminating the cabinet.
- Remove and replace inner cubicle bonding bracket with new item provided in upgrade kit (item 13)



13. Install the AEI900L/AEI1000L Modules

- Before the Installation of *each* AEI verify that DIP switches 1-4 (which configure the overvoltage behavior) on each AEI are set to the equivalent time setting as recorded in step 8 - Master SMPS Jumpers TP10 to TP13

SMPS Jumpers	AEI Switch
TP10	SW1
TP11	SW2
TP12	SW3
TP13	SW4




- Correctly set SW7 for the Compatibility Rating Mode required:

AEI Module Used	Upgraded Turbine Converter Current Rating	Position of SW7
AEI900L	2400 A (as before upgrade)	ON
AEI900L	2700 A	OFF
AEI1000L	3000 A	OFF

- Refer to AVID Document DTS-MID0012 section on User Selectable Options for complete information about these settings.

THESE SETTINGS ARE IMPORTANT, THE TURBINE WILL NOT RUN CORRECTLY UNLESS THEY ARE MADE.

- Install the 6 AEIs into the A12-1 and A12-2 cabinets
- Align with the M5 and M6 mounting locations used by the DELTA modules, firmly secure the AEI units with the M5 Torx screws and M6 bolts/washers retained when the DELTA modules were removed.




14. Connect Coolant Hoses, Front and Back

- Connect and secure each rear Plumbing Hose from the outlet manifold to the rear barb on all the AEI units.
- Connect and secure each hose from the inlet manifold to the front barb on all the AEI units



- *Tighten all hose clamps to 4Nm torque. A pre-set torque handle is provided in the upgrade kit for this purpose.*
- *IT IS CRITICAL THAT THE HOSES ARE SECURELY INSTALLED AND THE CLAMPS TIGHTENED CORRECTLY. COOLANT LEAKAGE WILL IRREPARABLY DAMAGE THE INVERTER UNITS.*

- Replace the splash shroud on each AEI




15. Reinstall DC Cables, Busbars and Fuse Links

- In Cubicle A12-1, reconnect all the DC negative and DC positive busbar to each AEI using the supplied M10 flange nuts and reusing the M10 hex bolt. Install the DC Link fuse busbar. Torque down all connections to 35Nm;




- In Cubicle A12-2, reconnect all the DC negative and DC positive busbar to each AEI using the supplied M10 flange nuts and reusing the M10 hex bolt. Install the DC Link fuse busbar. Torque down all connections to 35Nm.




16. Reinstall A12-1 Side Phase Cables

- Remove the cover plates from each AEI.
- Install the A12-1 side phase cables as identified on removal, using the supplied M10 flange nuts. Torque all connections to 35Nm.




17. Reinstall A12-2 AC Cables

- Remove the cover plates from each AEI.
- Install the A12-2 side phase cables as identified on removal, using the supplied M10 flange nuts. Torque all connections to 35Nm.




18. Reinstall AEI Cover Plates

- The following steps are the same for both GRID & GEN sides.
- Remount the cover plates to each AEI, as shown. Tighten down all M5 Hex Nuts firmly to secure to the AEI
- Remove, flip, and attach the EMC plates to join each adjacent AEI unit, and tighten down firmly with the provided M5 Hex Nuts




19. Install Auxiliary Power Units

- Mount the Auxiliary Power Units [Item 1] onto the AEI Cover Plates.
- Tighten the M5 Nylock nuts securely
- Connect the APU to the AEI as shown below:



- For each APU, plug the 4-pin connector into the corresponding AEI module:




20. Optional Connection of Auxiliary 24VDC Supply to APUs


- The AEI modules and CDCs may be powered from an auxiliary 24VDC supply, connected to the $\frac{+}{-}$ AUX. 24V DC input of the APU-G units.
- **Refer to Section 6 of the Auxiliary Power Unit – Type G Data Sheet (DTS-02175-ASY-A) for complete details.**
- Attention is drawn specifically to:
 - The rating of the auxiliary 24VDC supply must be adequate for the startup current of the AEIs.
 - If the auxiliary 24VDC supply to the APUs is used, it is recommended to disconnect the auxiliary 24VDC supply to the CDCs from TB1F on the I/O panels.

21. Install Ground Brackets and Ribbon Cables

- Install the offset ground brackets (*Items 6*) to allow the ribbon cables to route from the A12-1 & A12-2 cubicles into the control section using original M4 x 6 screws.




ITEM 6 – GRID SIDE




M4x6 TAPTITE

ITEM 4 – GRID SIDE FITTED

- This shows the ribbon routing (note that it shows a Type E APU, but the routing is the same for an APU-G).




- Connect and clamp down all ribbon cables to each AEI unit and tie wrap into place:




22. Reinstall Lower Cubicle Shrouds

- Referring to the figures below, reinstall lower cubicle shrouds into the A12-1 and A12-2 inverter cubicles.
- **DEPENDING ON THE EXACT CABINET CONSTRUCTION, IT MAY BE NECESSARY TO REMOVE (BY CUTTING) CERTAIN FLANGES ON THE SHROUDS TO AVOID INTERFERENCE WITH THE AEI OR APU MODULES.**
- **IT MAY ALSO BE NECESSARY TO REMOVE THE PLUGGABLE TERMINAL BLOCKS TB4, TB5 & TB6 FROM THE AEI MODULES. IF THE FUNCTIONALITY PROVIDED VIA THESE TB'S IS REQUIRED, PLEASE CONTACT AVID FOR SUPPLY OF REPLACEMENT SHROUDS.**



23. Reinstall Upper Cubicle Shrouds

- Referring to the figures below, reinstall the polycarbonate upper cubicle shrouds into the A12-1 and A12-2 inverter cubicles:




24. Turbine Restart

Background

- In normal operation, the CDC controllers are powered by the auxiliary 24V supply before the main DC link is energized (hence the Delta/AEI modules are not powered). This means that the CDC cannot identify the Delta/AEI modules – leading to faults that interfere with the Siemens control system. To avoid these faults, P10.36 instructs the CDC not to read data from the Deltas/AEIs, but to remember the previously identified values.
- After changing from Deltas to AEIs, it is necessary to perform at least one power cycle with P10.36 set to “Delta Bridge”. This causes the CDC to read the new information from the AEIs. After this has been successfully achieved, P10.36 can be returned to its normal position to avoid the faults prior to charging the DC link.
- It is also necessary to set the active-sharing parameters for the AEI drives to their default values in case they have been changed for the Delta system.
- ***This procedure will need to be repeated if either the GRID or GENERATOR CDC is replaced at a future date.***

Procedure




Note that TB1F (Aux Power In) is the 2-Way TB nearest the edge of the 20x4390 I/O board

25. Label CDCs

- If at any time a CDC module needs to be replaced with either a brand-new unit, or one that has previously operated with Delta modules, ***IT IS CRITICAL THAT THE ABOVE PROCEDURE IS FOLLOWED FOR THE REPLACEMENT CDC.***
- To help ensure this happens, the upgrade kit includes several copies of this label:



- Which should be attached to BOTH CDCs as shown:



- **Also, temporarily remove the CDCs and attach another copy of this label to the cabinet back-panel underneath the CDC so that it will be visible whenever the CDC is removed.**
- A total of eight copies of this label are provided in the upgrade kit (peelable from a single sheet). Place the sheet with the spare labels into the magnetic envelope provided so that they are available if the CDCs are replaced in the future.

26. Attach Documents for Reference

- Locate the magnetic clear plastic envelope supplied with the upgrade kit.
- Place one copy of the following documents inside:
 - DTS-01804-ASY-A - This Data Sheet
 - DTS-MID0012 - Avid Extreme Inverter Data Sheet
 - DTS-02175-ASY-A - Auxiliary Power Unit – Type G data Sheet
 - PRL-MID0169 - CDC Warning Label (spare copies)
- Attach the envelope to the inside of the control cabinet door:



27. Fit the Upgrade Identification Label

- The upgrade kit includes two weather-proof self-adhesive labels (Item 3) that may be applied to the turbine to clearly indicate that it has been upgraded with Avid Extreme Inverters:



- These may be applied on the interior or exterior of the turbine as-per customer preference (e.g. on the turbine door).
- Surface preparation wipes are also included in the kit.

28. Document Revision History

Rev.	Date	Author	Changes
00	July 27 2021	G. Pace	Document created
01	Oct 22 2021	G. Pace	Hose-clamp torque changed
02	Nov 17 2021	G. Pace	Add label to CDCs Further modifications to restart flowchart Polycarbonate shrouds to be re-used Upgrade identification label added Tighten manifold hose clamps before fitting AElS
03	Mar 24 2022	G. Pace	M10 electrical connection torques changed to 35Nm
04	April 12 2022	Z. Gordon	Added grid-side grounding bracket and cabinet modifications
05	April 25 2022	Z. Gordon	Added inner cubicle bonding bracket replacement instructions
06	August 1 2022	G. Pace	Installation check-list added
07	March 30 2023	G. Pace	Recommendation to replace DC fuses added
08	Dec 12 2023	G. Pace	Added instruction to place label on cabinet back-panel behind the CDCs
09	Aug 9 th 2024	M. Woods	Aux-Power-In on flow chart corrected to TB1F

29. Appendix A – Installation Checklist

Before Going to Turbine

CUSTOMER:		SITE NAME:	
TURBINE NUMBER:		AVID TECHNICIAN (or N/A):	
CUSTOMER LEAD TECHNICIAN:		DATE:	

All Tools Available:

Item	Initial	Item	Initial	Item	Initial
MV3000 Keypad with Cable		Diagonal wire cutters		8mm crescent wrench	
Torx T25 Driver		Phillips #2 x 4" Screwdriver		3/16" x 4" Slotted Screwdriver	
#3 Pozi-drive Screwdriver		Socket Wrench, 3/8" Drive		Torque Wrench, 3/8" Drive	
5mm Socket, 3/8" Drive		8mm Socket, 3/8" Drive		10mm Socket, 3/8" Drive	
17mm Socket, 3/8" Drive		Socket Extension 10" Long, 3/8" Drive		Adjustable Crescent Wrench, 1" Jaw Capacity	
Laptop with Drive Coach and RS232		10" 1/4" Drive Extension [*1]		1/4" Hex to 1/4" Drive Socket Adapter [*1]	
8mm 1/4" Drive Socket [*1]		Digital Voltmeter (DVM)		4 NM Torque Key [*1]	
Hydrometer Kit		AEI/Delta Installation Dolly (if available)		Torque Seal [*1]	
AEI/Delta Lift Hoist (if available)		Sheet metal / Lexan cutting tool			

[*1] : These items are provided as part of the AEI upgrade kit

AEI Upgrade Kit Complete

Refer to the upgrade kit parts list is section 5 of this Data Sheet.

UPGRADE KIT SERIAL NUMBER: _____

Item	Initials
All items in parts list correctly received	

Item	Initials
All documents in document list correctly received	

Turbine History

Was turbine in running condition before AEI upgrade?: _____

If turbine was not in running condition, please attach all available fault history (from SCADA or Drive Coach) and describe all known details of the fault / problem.

Description of attachments:

At Turbine, Before Removing Deltas

CUSTOMER:		SITE NAME:	
TURBINE NUMBER:		AVID TECHNICIAN (or N/A):	
CUSTOMER LEAD TECHNICIAN:		DATE:	

Status of Turbine:

Turbine Faults (if applicable)
(blown fuses, tripped breakers, system fault codes etc.):

Visible Damage (Before Removing Deltas)
(Damaged cables or ribbons, missing hardware, coolant leaks etc.) :

Check coolant with hydrometer and record result
If out of specification, coolant must be replaced before installation of AEI units:

Hydrometer Reading: _____ Units: _____ In Spec?: _____

Customer Lock-out Tag-Out Procedures complete: _____ System safe voltage checks AC & DC complete: _____

Position of all cables, ribbons, tie-wraps etc. recorded: _____

Identify and record GEN side master SMPS jumper settings (jumper 10-13) and record below:

Jumper 10: _____ Jumper 11: _____ Jumper 12: _____ Jumper 13: _____

Identify and record GRID side master SMPS jumper settings (jumper 10-13) and record below:

Jumper 10: _____ Jumper 11: _____ Jumper 12: _____ Jumper 13: _____

After Installation, Before Power-On

CUSTOMER:		SITE NAME:	
TURBINE NUMBER:		AVID TECHNICIAN (or N/A):	
CUSTOMER LEAD TECHNICIAN:		DATE:	

CHECK ITEM	Grid Position 1	Grid Position 2	Grid Position 3	Gen Position 1	Gen Position 2	Gen Position 3
AEI Serial #						
APU Serial #						
DIP Switches ON (circle those that are ON)	1 2 3 4 5 6 7 8 9 10 11 12	1 2 3 4 5 6 7 8 9 10 11 12	1 2 3 4 5 6 7 8 9 10 11 12	1 2 3 4 5 6 7 8 9 10 11 12	1 2 3 4 5 6 7 8 9 10 11 12	1 2 3 4 5 6 7 8 9 10 11 12
Power Terminal Torque set to 35Nm and sealed	Aph #1					
	Aph #2					
	Bph #1					
	Bph #2					
	Cph #1					
	Cph #2					
	DC+ #1					
	DC+ #2					
	DC- #1					
DC- #2						
Pull-test control wires						
DC fuses replaced						
Ribbon clamps secure and not damaging insulation						
Coolant hoses torqued to 4 Nm using torque- key						
All wires/cables correctly tie-wrapped						

Turbine Restart Checklist

CUSTOMER:		SITE NAME:	
TURBINE NUMBER:		AVID TECHNICIAN (or N/A):	
CUSTOMER LEAD TECHNICIAN:		DATE:	

All air purged from cooling system: _____ No coolant leaks detected: _____

Check and record the final values of the following parameters etc. for both GEN and GRID CDC:

Parameter Etc.	Expected Value	GEN Value	GRID Value	Notes
P99.00	3			
P99.05	2400, 2700 or 3000			Depends on AEI type and setting
P10.36	1			
P35.18	1			
P99.09	0			Return to zero <i>after</i> restart procedure
P1.32	Customer Preference			Return to its original value <i>after</i> restart procedure
CDC Part Number				
CDC LED Shape	Round or Square [R/S]			
CDC Firmware Version				
Parameter Set File				

List and Describe any Faults During Re-Start:

Confirm document envelope and all contents (see section 26) installed in cabinet: _____

Record the 2-digit display readouts on each AEI:

GEN #1: _____	GEN #2: _____
GEN #3: _____	GRID #1: _____
GRID #2: _____	GRID #3: _____

Additional Information:
